




INSTALLATION PROCEDURE FOR MOUNTING FLANGE KIT

THIS FLANGE KIT IS INTENDED FOR INSTALLATION IN A RECESSED CEILING CAVITY. IDENTIFY ALL PARTS AND READ THE FOLLOWING ASSEMBLY INSTRUCTIONS BEFORE PROCEEDING WITH THE INSTALLATION. TO PREVENT ELECTRICAL SHOCK, TURN OFF ELECTRICITY AT FUSE BOX BEFORE PROCEEDING.

COMPONENT CHECK LIST



5. TIGHTEN LOWER SCREW TO ADJUSTABLE BRACKET TO MAKE FLANGE KIT FLUSH WITH CEILING SURFACE. NEXT, TIGHTEN THUMB SCREW TO SECURE INTO PLACE.




1. CUT OPENING


1'x2' - 12 3/4" x 24 1/2"
2'x2' - 24 3/4" x 24 1/2"
1'x4' - 12 3/4" x 48 1/2"
2'x4' - 24 3/4" x 48 1/2"



6. INSTALL SAFETY CHAIN (BY OTHERS) FROM HOLES PROVIDED ON THE TOP OF SIDE FLANGE ASSEMBLY TO THE CEILING STRUCTURE.




2. INSTALL SIDE FLANGE ASSEMBLY.



7. *WIRE AND LAY FIXTURE INTO PLACE BY INSERTING ON AN ANGLE. FOR CONVENIENCE, REMOVE DOOR FRAME TO FACILITATE EASIER HANDLING



3. GENTLY TIGHTEN THUMB SCREWS ENSURING ADJUSTABLE BRACKET IS PRESSED LIGHTLY AGAINST DRYWALL. MAKE SURE **NOT** TO TIGHTEN ALL THE WAY.



8. SLIDE IN END FLANGE TRIM (IF ROW MOUNTED THEN ONLY REQUIRED AT START AND END OF RUN).



4. INSTALL END SPACER BARS AND TIGHTEN SCREWS. MAKE SURE ALL FOUR CORNERS ARE SQUARED BEFORE TIGHTENING. NOTE: LINE-UP RECTANGULAR CUT-OUT SLOT TO THE HEAD OF THE SCREW AND SLIDE IN WHEN PLACING.



9. INSTALLATION COMPLETE.

* FOR SHALLOW CEILING CAVITY, FIXTURE MAY BE SLID INTO PLENUM, PRIOR TO ASSEMBLY AND INSTALLATION OF FLANGE KIT (i.e. STEPS 2-5) AND THEN SLIDE INTO PLACE. CONTINUE TO STEP 7